

Instructions for installing CT4-2000 Summer Cover on units built after 3/15/04

1. Remove valve cover, top with drinkwells, and floating closures.
2. Mount bracket on tower of base with 3/8 x 1 1/2 " bolts, nuts and washers provided.
3. Place summer cover on base over mounting bracket. Place 3/8" x 1 1/2" flat washer over mounting stud and install 3/8" hex nut and tighten.

