



13830 CABLE HEATER - INSTALL INSTRUCTIONS

This heater is intended for use in keeping water supply pipes and hoses ice free. To install, connect one wire lead to the Neutral connection and the other wire lead to the switched wire of the thermostat. NOTE: This replacement heater is not required to be grounded so the green wire, which may be present in your current heater, is omitted.

Uncoil the cable heater and route around the valve according to the illustrations below. Attach the remaining part of the cable heater to the water supply as far down the supply tile as possible. Secure to valve, hose and water supply with the plastic ties provided. The cable heater may cross over itself but should not be bound tight at those locations.

CAUTION: The heater may touch supply pipes, hoses or electric wires without damage, however, wrapping or insulating the heater may cause damage. Installation must not cause any strain on wiring connections. Heater must not be immersed.



Pull cable up through stand pipe as shown below:
Use a piece of wire or similar, form a tall U shape and push it down through the stand pipe. Insert the cable heater in the curled end. Bend the cable heater so it will enter the stand pipe. Gently pull the cable heater up through the stand pipe. Remove pulling tool and straighten out the folded section of the cable heater.

